# Powering On your new Samsung Galaxy A9 Tablet

1. Locate the Power Button: The power button on the Galaxy A9 tablet is located on the right side of the device when facing the screen. It's located just above the volume buttons.



- 2. **Press and Hold the Power Button**: Gently press and hold the power button for a few seconds. You don't need to apply much force; just a firm press will do.
- 3. Wait for the Screen to Turn On: Once you press the power button, the screen should light up within a few seconds, displaying the Samsung logo or a welcome screen.
- 4. **Release the Power Button**: As soon as the screen lights up, you can release the power button. Your tablet will continue to boot up to the home screen or lock screen, depending on your settings.
- 5. Unlock Your Tablet (If Necessary): If you have a lock screen set up (e.g., PIN, pattern, password, or biometric), you'll need to unlock the device to access your apps and data.

# Charging your Samsung Galaxy A9 Tablet

Charging a Samsung Galaxy A9 tablet is a straightforward process. Here are step-by-step directions to ensure your tablet is charged and ready to use:

1. Locate the Charging Port: The charging port is typically located at the bottom of the tablet. It's where you'll connect the charging cable.



2. **Prepare the Charger**: Use the charger that came with your Galaxy A9 tablet for optimal charging.



**USB** Cable

3. **Connect the Charging Cable to Your Tablet**: Locate the charging port on your tablet (pictured above) and insert the end of the USB cable into this port. Be gentle and make sure it's properly aligned to avoid damage.

- 4. **Check the Charging Indicator**: Once connected, the screen of your Galaxy A9 tablet should light up with a charging icon or notification. This indicates that the tablet is charging.
- 5. Let the Tablet Charge: Leave your tablet undisturbed while it charges. Charging time can vary based on battery level.
- 6. **Disconnect Once Charged**: When the tablet is fully charged, it's a good practice to disconnect the charger to prevent overcharging. Gently remove the cable from the tablet's charging port and then unplug the charger from the outlet.

# Connecting your Samsung Galaxy A9 Tablet to Wi-Fi

### 1. Access the Settings Menu:

a. From the Home screen of your Samsung Galaxy A9 tablet, swipe from the right to left to access the additional menu that includes the "Settings" icon.



b. Find and tap on the "Settings" icon as seen below.



### 2. Go to Connections Settings:

a. With the Settings menu open, select "Connections".

	Ved, 3 Jan G 🖬 🖬 •					4
Se	ettings	Q	Connections			
0	Connections Wi-Fi • Bluetooth • Flight mode		Wi-Fi			
0	Connected devices Quick Share • Samsung DeX		Bluetooth			C
			Flight mode			
C	Modes and Routines Modes • Routines		Data usage			
•	Sound mode • Ringtone		Tethering			
0	Notifications Status bar • Do not disturb		More connection settings			
	Display		Looking for something else?			
<b>**</b>	0.0			111	0	

#### 3. Select Wi-Fi:


a. In the Connections menu, tap on "Wi-Fi" to open Wi-Fi settings.

1 Wed, 3 Jan GOO •				≪ ≈ 36%∎
Settings Q	Connections			
Connections WI-FI • Bluetooth • Flight mode	Wi-Fi			•
Connected devices     Quick Share - Samsung DeX	Bluetooth			•
	Flight mode			
Modes • Routines	Data usage			
Sound Mode • Ringtone	Tethering			
Notifications     Status bar • Do not disturb	More connection settings			
Display	Looking for something else?			
		111	0	<

#### 4. Select a Network:

a. Once Wi-Fi is enabled, a list of available networks will appear. Scroll through the list until you find the network you would like to connect to and tap on its name.

**NOTE:** "Home Wifi" is an example utilized for demonstration purposes, please look for the name of your personal wifi when connecting to your home internet.




### 5. Enter the Wi-Fi Password:

a. If the network you selected is secured, you will be prompted to enter a password. Type in the network's password and then tap "Connect".

10:00	i -		al 🛢
Settings Q		< Home Wifi	
Profil	nsung account e · Apps and features	Password	
0	Connections Wi-Fi • Bluetooth • Flight mode	Auto reconnect	
0	Connected devices Quick Share - Android Auto	<ul> <li>View more</li> </ul>	
		Connect	
©	Modes and Routines Modes - Routines		
•	Sound Sound mode • Ringtone		

## 6. Connected to Wi-Fi:

a. After a moment, you should see a Wi-Fi symbol appear in the status bar at the top of your screen, indicating you are connected and ready to begin using your Age of Learning programs.



# Powering Off your Samsung Galaxy A9 Tablet

6. **Locate the Power Button**: The power button on the Galaxy A9 tablet is located on the right side of the device when facing the screen. It can be found just above the volume buttons.



- 7. **Press and Hold the Power Button**: Gently press and hold the power button for a few seconds. You don't need to apply much force; just a firm press will do.
- 8. Wait for the Screen to Turn Off: Once you press (and hold) the power button, you will be prompted with a menu to either "Shutdown" or "Restart" the tablet. Select "Shutdown" and the screen will go dark and shutdown the device.